


Skype connect


Notice: The fee of your business account is must more than €50 when you use the account first time.

1. https://login.skype.com

Sign in with the business accounts.



2. When you have sign in, in the end of this page, please select the Business; then select the Sign in, please click it.



3. Please click the Feature Menu

The screenshot shows a navigation bar with icons for home, users, features, and a search icon. On the right, it displays '€0,30' and a 'Buy Skype Credit' button. A sidebar on the left lists various services: Credit allocations (0 members), Subscriptions (0 members), Group video calling (0 members), Voicemail (0 members), Skype Numbers (0 members), Call forwarding (0 members), and Skype Connect (9 profiles). The main content area features a 'Skype Credit' section with a coin icon, explaining that allocated credit allows users to call landlines and mobiles and send text messages. It also mentions the option to set up auto-recharge. A blue button labeled 'Allocate Skype Credit' is visible.

Then please click the **Skype connect**

This screenshot shows the 'Skype Connect' section of the interface. The sidebar on the left includes Subscriptions (0 members), Group video calling (0 members), Voicemail (0 members), Online Numbers (0 members), Call forwarding (0 members), and Skype Connect (3 profiles). The main area has a heading 'Your SIP Profiles' and a blue button 'Set up a SIP Profile'. A red warning box contains the message: 'Some of your SIP Profiles have been suspended because your Skype Manager has insufficient credit available to pay for the channel subscription. Buy more credit and the profiles will be reactivated.' A link 'Learn more' is also present.

4.Create a SIP profile

Create a SIP profile

- 1 Choose name
- 2 Set up subscription
- 3 Authentication


Creating a SIP profile is as easy as three steps. Simply choose a name for your profile, purchase a channel subscription, and get your authentication details.

Choose a profile name

For example, "New York office". You can edit this name later.

[Next](#) [Cancel](#)


Then you can create one sip account, you need pay for **€ 4.95** for one channel as monthly rent and you need input those register information to our voip trunk blank, then you can register to skype server. And then you need assign money for **outgoing calls**, then you can call out.



The screenshot shows the 'Profile settings' interface for a SIP profile named 'aaa'. On the left is a sidebar with navigation options: 'Profile settings' (selected), 'Authentication details', and 'Reports'. Below these is a link '« Back to SIP Profile list'. The main content area is titled 'Profile settings' and includes:

- Profile name:** aaa
- Calling channels:** Buy a channel subscription to activate this profile
- Outgoing calls:** Set up outgoing calls. A text block explains that outgoing calls require adding Skype credit and provides a link to 'Skype's standard per minute rates'. Below this text are buttons for 'Add credit' and 'Auto-recharge settings'. At the bottom, there is a credit input field showing '€ 0.30' and an 'Add credit' button.

Then you can see the sip account information, please click the **Authentications details**.



The screenshot shows the 'Authentication details' page for the 'aaa' profile. The sidebar on the left has 'Authentication details' selected. The main content area is titled 'Authentication details' and contains:

- A heading: 'Please choose the method of authentication needed for your PBX.'
- Two radio button options: 'Registration (Username/password)' (which is selected) and 'or, IP Authentication ?'.
- A list of fields:
 - SIP User:** 99051000142212
 - Password:** KK3UyppyJwr5Wm, with a 'Generate a new password' link.
 - Skype Connect address:** sip.skype.com
 - UDP Port:** 5060
- A warning icon and text: '⚠ SIP user is not yet registered at sip.skype.com'

5.Settings on IPPBX

A.build one sip trunk with skype for sip account

In the trunk of our IPPBX setting:

| | |
|---|--|
| <p>Provider Type:</p> <p><input type="radio"/> Analog Trunk</p> <p><input checked="" type="radio"/> Custom Trunk</p> <p><input type="radio"/> Peer</p> | <p>Description: <input type="text" value="skype"/></p> <p>Protocol: <input type="text" value="SIP"/></p> <p>DialPlan: <input type="text" value="default"/></p> <p>Register: <input checked="" type="checkbox"/></p> <p>Host: <input type="text" value="sip.skype.com"/></p> <p><input type="checkbox"/> Without Authentication</p> <p>Username: <input type="text" value="9905000001545"/></p> <p>Password: <input type="text" value="....."/></p> |
|---|--|

B.set one outbound rule

X

Rule Name:

Place this call through :

Failover :

PIN Set:

Dialing Rules : If the number begins with and followed by (more than) digits (define a custom pattern)

Delete digits from the front and auto-add digit before dialing

C.make an outbound call

After we have done above, in the extension we can dial 00 + Country Code + City Area Code + local number to dial out via skype line

For example: Dial number 00862885337096 will contact our company.

D.set inbound rule

Inbound Routing of our IPPBX:

X

Route

from Trunk

Destination